

Delete drawing segmentation

Posted on July 30, 2026 by Smaheine


You can remove an existing segmentation to return to the initial drawing display.

Delete the segmentation

1. Open the segmented drawing.
2. Go back to the segmentation screen.
3. Click **Delete**.

The segmentation and detected zones are removed from the drawing.

Découverte de localisations



1. Cliquez sur « Supprimer »

ANNULER SUPPRIMER

PROJET	OBJET	PROJET	PROJET
IMMEUBLE DE LOGEMENTS			
PARIS			
BELLEVILLE			
Atelier d'Architecture Lalo			
145 rue de Belleville, 75011 PARIS Tél 01 43 14 43 17 20			
COORDONATEUR TECHNIQUE			
CONTRÔLEUR QPS			
PROFESSEUR			
PROFESSEUR			
Atelier d'Architecture Lalo			
			
PRO			
PLAN NIVEAU R+2			
43.72 M2			
Affaire 033-PROJ Date 01/12/2025 Eché 1/100			
PROJ	PAI	PROJ	PAI
PROJ	PAI	PROJ	PAI