

How to share a project with a collaborator?

Posted on June 30, 2026 by Smaheine

Project sharing is only available from **Archipad Web**, and can be performed by the project owner or a project administrator.

To share a project, go to the **Information** menu, then open the **Sharing** section.

You can then add the collaborator and set their access level.